

Component Procedures: Evaporative Vapor Pressure Sensor

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Evaporative Vapor Pressure Sensor

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Pressure Sensor	13579380	Pressure Sensor	72.83	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Vapor Canister > Pressure Sensor, R&R	B	3.1	0.0