

Component Procedures: Antenna Control Module

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Antenna Control Module

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Antenna & Radio > Module, R&R	B	1.3	0.0