

Component Procedures: Parking Assist Warning Indicator

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Parking Assist Warning Indicator

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	Alarm Module	B	1.6	0.0