

# **Component Procedures: Passenger Assist Handle**

## **Table of Contents**

1. Coat Hook Replacement (Coupe) (Article 10076)

## **Component Procedures: Passenger Assist Handle**

### **Coat Hook Replacement (Coupe) (Article 10076)**

Callout Component Name

1 Coat Hook Fastener Caution: Refer to Fastener Caution . Procedure Use a small flat-bladed tool to open the integral coat hook cover to access the screw. Tighten 6 Nm (53 lb in)

Procedure

Use a small flat-bladed tool to open the integral coat hook cover to access the screw.

6 Nm (53 lb in)

2 Coat Hook Assembly