

# **Component Procedures: Power Window Switch**

## **Table of Contents**

1. Parts and Labor (itype\_189)
2. Front Side Door Window Switch Replacement (Article 10267)

# Component Procedures: Power Window Switch

## Parts and Labor (itype\_189)

### Parts

Qualifier	Part #	Name	Price	Note
Window Switch > Right	92221585	Window Switch	29.37	
Window Switch > Left > Coupe	22806290	Window Switch	0.00	
Window Switch > Left > Conve?	20955380	Window Switch	42.72	

### Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Door > Window Switch, R&R > Each	B	0.4	0.3

## Front Side Door Window Switch Replacement (Article 10267)

Callout Component Name

Preliminary Procedure Remove the door trim panel. Refer to Front Side Door Trim Panel Replacement .

Preliminary Procedure

Remove the door trim panel. Refer to Front Side Door Trim Panel Replacement .

1 Front Side Door Window Switch Assembly Tip: Use a flat bladed tool to release the switch from the trim panel.