

Component Procedures: Oil Pressure Sender

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Oil Pressure Sender

Parts and Labor (itype_189)

Parts

| Qualifier | Part # | Name | Price | Note |
|---------------------------|----------|-------------------------|-------|------|
| Oil Pressure Sending Unit | 12621649 | Oil Pressure Sending U? | 34.46 | |