

Component Procedures: Parking Brake Cable

Table of Contents

1. Parts and Labor (itype_189)
2. Parking Brake Rear Cable Replacement (Article 10718)

Component Procedures: Parking Brake Cable

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Rear Cable	22740875	Rear Cable	77.69	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Parking Brake > Front Cable, R&R	B	2.1	0.0
Remove & Replace	Parking Brake > Rear Cable, R&R > One Side	B	0.5	0.0
Remove & Replace	Parking Brake > Rear Cable, R&R > Both Sides	B	0.7	0.0

Parking Brake Rear Cable Replacement (Article 10718)

Removal Procedure

- Raise and support the vehicle. Refer to Lifting and Jacking the Vehicle .
- Remove the exhaust muffler intermediate heat shield. Refer to Exhaust Muffler Intermediate Heat Shield Replacement .
- Remove the fuel tank heat shield. Refer to Fuel Tank Replacement .
- Pull the rear park brake cable equalizer (1) forward and disengage the front park brake cable from the equalizer. Click for full-size image
- Release the rear park brake cable ferrules (2) from the retaining bracket. Push the cable ferrules rearward to release.
- Release the rear park brake cables from the 2 retainers (1) on the fuel tank. Click for full-size image
- Release the rear park brake cables from the retainer (1) on each side of the rear suspension cradle. Click for full-size image
- Disconnect the rear park brake cable eyes (1) from the park brake actuator s. Click for full-size image
- Release the rear park brake cable ferrules (2) from the suspension knuckles. Push the cable ferrules forward to release.
- Remove the rear park brake cable assembly.

Installation Procedure

- Install the rear park brake cable assembly. Click for full-size image
- Connect the rear park brake cable eyes (1) to the park brake actuator s.
- Install the rear park brake cable ferrules (2) to the suspension knuckles. Seat the cable ferrules fully in suspension knuckles.
- Install the rear park brake cables to the retainer (1) on each side of the rear suspension cradle. Click for full-size image
- Install the rear park brake cables to the 2 retainers (1) on the fuel tank. Click for full-size image
- Pull the rear park brake cable equalizer (1) forward and connect the front park brake cable to the equalizer. Click for full-size image
- Install the rear park brake cable ferrules (2) to the retaining bracket. Seat the cable ferrules fully in the retaining bracket.
- Install the fuel tank heat shield. Refer to Fuel Tank Replacement .
- Install the exhaust muffler intermediate heat shield. Refer to Exhaust Muffler Intermediate Heat Shield Replacement .
- Apply and release the park brake lever 2–3 times to set the park brake cable tension and inspect for proper operation.