

# **Component Procedures: Stabilizer Bushing**

## **Table of Contents**

1. Parts and Labor (itype\_189)
2. Front Suspension (Article 13539)
3. Rear Suspension (Article 13583)

# Component Procedures: Stabilizer Bushing

## Parts and Labor (itype\_189)

### Parts

Qualifier	Part #	Name	Price	Note
Front Suspension > Bushings	92199900	13 - Bushings	0.00	
Rear Suspension > Bushings	92199900	15 - Bushings	0.00	

### Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Front Suspension > Stabilizer Bar > Bushings, ?	C	0.5	0.3
Remove & Replace	Rear Suspension > Stabilizer Bar > Bushings, ?	C	0.9	0.0
Remove & Replace	Rear Suspension > Stabilizer Bar > Bushings, ?	C	1.1	0.0

## Front Suspension (Article 13539)

### Non Standards

- Stabilizer Shaft Insulator Replacement (13540)

## Rear Suspension (Article 13583)

### Non Standards

- Stabilizer Shaft Insulator Replacement (13584)