

Component Procedures: Differential Carrier

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Differential Carrier

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Rear Axle > Carrier > Manual?	22928326	6 - Carrier	0.00	
Rear Axle > Carrier > Auto T?	20993935	6 - Carrier	0.00	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Install	Rear Axle > Final Drive Assembly, R&I	B	5.5	4.1
Remove & Install	Rear Axle > Final Drive Assembly, R&I > NOTE ?		0.4	
Remove & Install	Rear Axle > Final Drive Assembly, R&I > NOTE ?		0.2	
Remove & Install	Rear Axle > Final Drive Assembly, R&I > NOTE ?		0.1	
Remove & Install	Rear Axle > Final Drive Assembly, R&I > NOTE ?		0.8	
Remove & Install	Rear Axle > Final Drive Assembly, R&I > NOTE ?		0.5	
Remove & Install	Rear Axle > Final Drive Assembly, R&I > NOTE ?		0.2	
Remove & Install	Rear Axle > Final Drive Assembly, R&I > NOTE ?		0.2	
Remove & Install	Rear Axle > Final Drive Assembly, R&I > NOTE ?		1.0	
Remove & Install	Rear Axle > Final Drive Assembly, R&I > NOTE ?		0.4	
Remove & Replace	Rear Axle > Final Drive Assembly, R&R > See F?			0.0