

Component Procedures: Speaker

Table of Contents

1. Parts and Labor (itype_189)
2. Speaker Replacement Reference (Article 10971)
3. Radio Front Center Speaker Replacement (Article 10991)
4. Radio Front Speaker Grille Replacement (Article 10994)
5. Radio Front Side Door Upper Speaker Grille Replacement (Article 10993)
6. Radio Front Side Door Speaker Replacement (Article 10992)
7. Radio Rear Speaker Replacement (Convertible) (Article 10995)
8. Radio Rear Speaker Replacement (Coupe) (Article 10996)
9. All Technical Service Bulletins (itype_100)
10. Repair Tips (itype_110)

Component Procedures: Speaker

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Antenna & Radio > Speaker, R&R > Door > One S?	B	0.6	0.0
Remove & Replace	Antenna & Radio > Speaker, R&R > Front Center	B	0.5	0.0
Remove & Replace	Antenna & Radio > Speaker, R&R > Rear Shelf >?	B	0.8	0.0
Remove & Replace	Antenna & Radio > Speaker, R&R > Rear Shelf >?	B	0.9	0.0

Speaker Replacement Reference (Article 10971)

Component Repair Instruction

Center I/P Speaker Radio Front Center Speaker Replacement

Front Tweeter Speaker Radio Front Side Door Upper Speaker Grille Replacement

Front Door Speaker s Radio Front Side Door Speaker Replacement

Rear Speaker s/Subwoofers Radio Rear Speaker Replacement

Radio Front Center Speaker Replacement (Article 10991)

Callout Component Name

Preliminary Procedure Remove the radio front speaker grille. Refer to Radio Front Speaker Grille Replacement .

Preliminary Procedure

Remove the radio front speaker grille. Refer to Radio Front Speaker Grille Replacement .

1 Radio Front Speaker Bolt/Screw (Qty: 2) Caution: Refer to Fastener Caution . Tighten 2.5 Nm (22 lb in)

2.5 Nm (22 lb in)

2 Radio Front Speaker Procedure Disconnect the electrical connectors.

Procedure

Disconnect the electrical connectors.

Radio Front Speaker Grille Replacement (Article 10994)

Callout Component Name

1 Radio Front Speaker Grille Procedure Using a flat bladed tool, gently unsnap speaker grille from the instrument panel trim pad. The grille is attached with four integral clips.

Procedure

Using a flat bladed tool, gently unsnap speaker grille from the instrument panel trim pad. The grille is attached with four integral clips.

Radio Front Side Door Upper Speaker Grille Replacement (Article 10993)

Callout Component Name

1 Radio Front Side Door Upper Speaker Grille Procedure Using plastic trim tool, release 3 retainers, and pull speaker grille assembly straight up

Procedure

Using plastic trim tool, release 3 retainers, and pull speaker grille assembly straight up

2 Radio Front Side Door Upper Speaker Grille Bolt Caution: Refer to Fastener Caution . Tighten 2 Nm (18 lb in)

2 Nm (18 lb in)

3 Radio Front Side Door Upper Speaker Procedure Disconnect electrical connector. Separate the speaker grille halves. Unclip speaker from grille.

- Disconnect electrical connector.

- Separate the speaker grille halves.

- Unclip speaker from grille.

Radio Front Side Door Speaker Replacement (Article 10992)

Callout Component Name

Preliminary Procedure Remove the front side door trim panel. Refer to Front Side Door Trim Panel Replacement .

Preliminary Procedure

Remove the front side door trim panel. Refer to Front Side Door Trim Panel Replacement .

1 Radio Front Side Door Speaker Bolt/Screw Caution: Refer to Fastener Caution . Tighten 2.5 Nm (22 lb in)

2.5 Nm (22 lb in)

2 Radio Front Side Door Lower Speaker Procedure Disconnect the electrical connector.

Procedure

Disconnect the electrical connector.

Radio Rear Speaker Replacement (Convertible) (Article 10995)

Callout Component Name

Preliminary Procedure Rear Seat Back Cushion Removal and Installation

Preliminary Procedure

Rear Seat Back Cushion Removal and Installation

1 Radio Rear Speaker Nut [4x] Caution: Fastener Caution Tighten 9Nm (80 lb in)

9Nm (80 lb in)

2 Radio Rear Speaker Procedure Disconnect the electrical connector.

Procedure

Disconnect the electrical connector.

Radio Rear Speaker Replacement (Coupe) (Article 10996)

Callout Component Name

Preliminary Procedure Remove the rear window shelf trim panel. Refer to Rear Window Panel Trim Replacement .

Preliminary Procedure

Remove the rear window shelf trim panel. Refer to Rear Window Panel Trim Replacement .

1 Radio Rear Speaker Bolt/Screw Caution: Refer to Fastener Caution . Tighten 2.5 Nm (22 lb in)

2.5 Nm (22 lb in)

2 Radio Rear Speaker Procedure Disconnect the electrical connectors.

Procedure

Disconnect the electrical connectors.

All Technical Service Bulletins (itype_100)

Tsbs

- Audio System - Buzz/Rattle From Rear Speaker Area (P11249, 2014/05/27)

Repair Tips (itype_110)

Tsbs

- Audio System - Buzz/Rattle From Rear Speaker Area (P11249, 2014/05/27)