

Component Procedures: Seat Position Sensor

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Seat Position Sensor

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Supplemental Restraint System > Passenger Sen?	B	1.1	0.8