

Component Procedures: Windshield Washer Switch

Table of Contents

1. Windshield Wiper and Windshield Washer Switch Replacement (Article 10517)

Component Procedures: Windshield Washer Switch

Windshield Wiper and Windshield Washer Switch Replacement (Article 10517)

Callout Component Name

Preliminary Procedure Remove the steering column shroud. Refer to Steering Column Shroud Replacement .

Preliminary Procedure

Remove the steering column shroud. Refer to Steering Column Shroud Replacement .

1 Windshield Wiper and Washer Switch Procedure Disconnect any electrical connectors as needed. Release the plastic retaining tabs and remove the windshield wiper and washer switch from the turn signal switch bracket.

Procedure

- Disconnect any electrical connectors as needed.
- Release the plastic retaining tabs and remove the windshield wiper and washer switch from the turn signal switch bracket.