

Component Procedures: Hood Hinge

Table of Contents

1. Hood Hinge Replacement (Article 10122)

Component Procedures: Hood Hinge

Hood Hinge Replacement (Article 10122)

Callout Component Name

Preliminary Procedures Remove the hood . Refer to Hood Replacement . Remove the appropriate front fender . Refer to Front Fender Replacement .

Preliminary Procedures

- Remove the hood . Refer to Hood Replacement .
- Remove the appropriate front fender . Refer to Front Fender Replacement .

1 Hood Hinge Bolt (Qty: 2) Caution: Refer to Fastener Caution . Procedure Mark the location of the hinge to the hood and upper rail with a grease pencil to aid in alignment. Tighten 25 Nm (18 lb ft)

Procedure

Mark the location of the hinge to the hood and upper rail with a grease pencil to aid in alignment.

25 Nm (18 lb ft)

2 Hood Hinge