

Component Procedures: Clutch Pedal Position Sensor / Switch

Table of Contents

1. Clutch Pedal Position Sensor Replacement (Article 14034)
2. AISIN AY6 (MV5) - Manual Transmission (Article 14047)
3. Tremec 6-Speed (M10, MG9, MM6) - Manual Transmission (Article 14139)

Component Procedures: Clutch Pedal Position Sensor / Switch

Clutch Pedal Position Sensor Replacement (Article 14034)

Callout Component Name

Preliminary Procedure Remove the clutch pedal assembly from the vehicle. Refer to Clutch Pedal Replacement

Preliminary Procedure

Remove the clutch pedal assembly from the vehicle. Refer to Clutch Pedal Replacement

1 Clutch Pedal Position Sensor Bolt Caution: Refer to Fastener Caution . Tighten 2.5 Nm (22 lb in)

2.5 Nm (22 lb in)

2 Clutch Pedal Position Sensor Procedure Perform the clutch pedal position sensor learn procedure. For the V6 engine refer to Clutch Pedal Position Learn or Clutch Pedal Position Learn for the V8 engine.

Procedure

Perform the clutch pedal position sensor learn procedure. For the V6 engine refer to Clutch Pedal Position Learn or Clutch Pedal Position Learn for the V8 engine.

AISIN AY6 (MV5) - Manual Transmission (Article 14047)

Non Standards

- Clutch Pedal Position Learn (14048)

Tremec 6-Speed (M10, MG9, MM6) - Manual Transmission (Article 14139)

Non Standards

- Clutch Pedal Position Learn (14140)