

Component Procedures: Rear Door Exterior Handle

Table of Contents

1. Front and Rear Side Door Outside Handle Rod Clip Replacement (Article 10477)

Component Procedures: Rear Door Exterior Handle

Front and Rear Side Door Outside Handle Rod Clip Replacement (Article 10477)

Removal Procedure

- Using the appropriate tool, open the outside door handle rod clip (1) on the latch. [Click for full-size image](#)
- Remove the old outside door handle rod clip from the door latch. [Click for full-size image](#)

Installation Procedure

- Install the new outside door handle rod clip (1) to the latch. [Click for full-size image](#)
- Verify the outside door handle will release the door latch.