

Component Procedures: Front Door Striker

Table of Contents

1. Front Side Door Lock Striker Adjustment (Article 10483)
2. Parts and Labor (itype_189)
3. Front Side Door Lock Striker Replacement (Article 10484)
4. Front Side Door Interlock Striker Replacement (Article 10479)

Component Procedures: Front Door Striker

Front Side Door Lock Striker Adjustment (Article 10483)

- Ensure that the door is properly aligned with the door opening before proceeding with the striker adjustment. [Click for full-size image](#)
- Open and close the door on the striker (2). Note if the door drags on the striker causing the door to move upward or downward upon contact with the striker. Also note the closing effort to fully engage the latch.
- Using a soft marker, mark around the striker (2) for reference of the original position. Loosen the striker screws just enough to allow the movement of the door striker and shims if equipped. [Click for full-size image](#)
- Use a rubber mallet or a suitable tool to adjust door striker up or down or inboard or outboard as required. [Click for full-size image](#)
- Move the striker to eliminate drag on the striker and door latch and to achieve proper door position within door opening. Start with up/down position, then position the striker to achieve proper alignment to the door opening. Set the in/out adjustment for proper door seal engagement ensuring that the door closing efforts are correct.
- Adjust the spacers as required and tighten the screws to 25 Nm (18 lb ft) .
- Inspect the door latch system for proper operation.
- Close the door.

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Striker	13503000	Striker	0.00	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Door > Striker, R&R > One Side	C	0.2	0.2

Front Side Door Lock Striker Replacement (Article 10484)

Callout Component Name

1 Front Side Door Latch Striker Screw (Qty: 2) Caution: Refer to Fastener Caution . Tighten 25 Nm (18 lb ft) 25 Nm (18 lb ft)

2 Front Side Door Latch Striker Procedure Ensure that all spacers are installed with the striker. Ensure that all spacers are in place. Refer to Front Side Door Lock Striker Adjustment Inspect the door latch system for proper operation.

Procedure

- Ensure that all spacers are installed with the striker.
- Ensure that all spacers are in place. Refer to Front Side Door Lock Striker Adjustment
- Inspect the door latch system for proper operation.

Front Side Door Interlock Striker Replacement (Article 10479)

Callout Component Name

1 Front Side Door Interlock Striker Bolt Caution: Refer to Fastener Caution . Tighten 10 Nm (89 lb in) 10 Nm (89 lb in)

2 Front Side Door Interlock Striker Plate Screw (Qty: 2) Caution: Refer to Fastener Caution . Tighten 10 Nm (89 lb in)

3 Front Side Door Interlock Striker Plate Procedure After replacing the interlock striker plate close the door lightly to ensure alignment to the interlock striker bolt. If the front door needs alignment. Refer to Front Side Door Replacement .

Procedure

After replacing the interlock striker plate close the door lightly to ensure alignment to the interlock striker bolt. If the front door needs alignment. Refer to Front Side Door Replacement .