

# **Component Procedures: Front Door Latch**

## **Table of Contents**

1. Parts and Labor (itype\_189)
2. Front Side Door Latch Replacement (Article 10480)
3. All Technical Service Bulletins (itype\_100)
4. Repair Tips (itype\_110)

# Component Procedures: Front Door Latch

## Parts and Labor (itype\_189)

Parts And Labor

Parts

Qualifiers

- Lock

## Front Side Door Latch Replacement (Article 10480)

Callout Component Name

Preliminary Procedures Remove the front side door trim panel . Refer to Front Side Door Trim Panel Replacement

.

Preliminary Procedures

Remove the front side door trim panel . Refer to Front Side Door Trim Panel Replacement .

1 Front Side Door Latch Screw (Qty: 3) Caution: Refer to Fastener Caution . Procedures Remove the front side door water deflector. Disconnect the electrical connector. Release the front side door outside handle rod mechanism at shift linkage lever - clip. Release the front side door lock cylinder rod from the door latch.

Tighten 10 Nm (89 lb in)

Procedures

- Remove the front side door water deflector.
- Disconnect the electrical connector.
- Release the front side door outside handle rod mechanism at shift linkage lever - clip.
- Release the front side door lock cylinder rod from the door latch.

10 Nm (89 lb in)

2 Front Side Door Latch Procedure Inspect the door latch system for proper operation.

Procedure

Inspect the door latch system for proper operation.

## All Technical Service Bulletins (itype\_100)

Tsbs

- Body - Door Latch Diagnostic Procedures (PI0011C, 2013/05/29)

## Repair Tips (itype\_110)

Tsbs

- Body - Door Latch Diagnostic Procedures (PI0011C, 2013/05/29)