

Component Procedures: Suspension Spring (Coil / Leaf)

Table of Contents

1. Parts and Labor (itype_189)
2. Rear Suspension (Article 13578)
3. Front Suspension (Article 13550)

Component Procedures: Suspension Spring (Coil / Leaf)

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Front Suspension > Coil Sprig?	20953579	6 - Coil Spring	0.00	
Front Suspension > Coil Sprig?	20954689	6 - Coil Spring	0.00	
Front Suspension > Coil Sprig?	92245256	6 - Coil Spring	0.00	
Rear Suspension > Coil Spring	92195466	10 - Coil Spring	0.00	
Bumper > Front Suspension	13219136	8 - Bumper	0.00	
Bumper > Rear Suspension	NOT LISTED	8 - Bumper	0.00	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Front Suspension > Suspension Components > Co?	B	1.4	1.1
Remove & Replace	Front Suspension > Suspension Components > Co?	B	2.6	2.0
Remove & Replace	Rear Suspension > Suspension Components > Coi?	B	1.2	0.0
Remove & Replace	Rear Suspension > Suspension Components > Coi?	B	2.4	0.0

Rear Suspension (Article 13578)

Non Standards

- Shock Absorber, Shock Absorber Component, or Spring Replacement (W/FE5) (13579)
- Shock Absorber, Shock Absorber Component, or Spring Replacement (WO/FE5) (13581)

Front Suspension (Article 13550)

Non Standards

- Strut, Strut Component, or Spring Replacement (13551)