

Component Procedures: Extension Housing

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Extension Housing

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Manual Transmission > Rear Extension Seal, R&R	B	1.8	1.4