

Component Procedures: Shift Cable

Table of Contents

1. Parts and Labor (itype_189)
2. Automatic Transaxle (Article 44423)
3. Automatic Transaxle (Article 44425)

Component Procedures: Shift Cable

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Gear Shift Control	46790F2100	Shift Control Cable	166.16	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Gear Shift Control > Shift Control Cable, R&R	B	1.5	0.0
Adjust	Gear Shift Control > Shift Control Cable, Adj?	B	0.4	0.0

Automatic Transaxle (Article 44423)

Non Standards

- Shift Cable - Components and Components Location (44424)

Automatic Transaxle (Article 44425)

Non Standards

- Shift Cable - Repair Procedures (44426)