

Component Procedures: Negative Battery Cable

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Negative Battery Cable

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Battery > Negative Cable, R&R	B	0.4	0.0