

Component Procedures: Shift Cable

Table of Contents

1. Parts and Labor (itype_189)
2. M6CF3-1 - Manual Transaxle (Article 44524)
3. M6CF3-1 - Manual Transaxle (Article 44528)

Component Procedures: Shift Cable

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Gear Shift Control	43794F3200	Shift Control Cable	209.44	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Gear Shift Control > Shift Control Cable, R&R	B	1.5	0.0
Adjust	Gear Shift Control > Shift Control Cable, Adj?	B	0.4	0.0

M6CF3-1 - Manual Transaxle (Article 44524)

Non Standards

- Control Cable - Components and Components Location (44525)

M6CF3-1 - Manual Transaxle (Article 44528)

Non Standards

- Control Cable - Repair Procedures (44529)