

Component Procedures: Brake Pad

Table of Contents

1. Parts and Labor (itype_189)
2. Specifications Quick Reference (itype_439)

Component Procedures: Brake Pad

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Brake Components > Front Pads	58101F3A00	Us Built	86.29	
Brake Components > Front Pad?	58101F2A50	With Sport	83.94	
Brake Components > Front Pad?	58101F2A00	Without Sport	83.94	
Brake Components > Rear Pads	58302F2A30	Korea Built	66.82	
Brake Components > Rear Pads	58302F3A30	Us Built	68.69	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Brake Components > Brakes, R&R > Front Pads	B	0.9	0.0
Remove & Replace	Brake Components > Brakes, R&R > Front Pads >?		0.2	
Remove & Replace	Brake Components > Brakes, R&R > Front Pads >?		0.3	
Remove & Replace	Brake Components > Brakes, R&R > Front Pads >?		0.2	
Remove & Replace	Brake Components > Brakes, R&R > Front Pads >?		0.1	
Remove & Replace	Brake Components > Brakes, R&R > Front Pads >?		0.2	
Remove & Replace	Brake Components > Brakes, R&R > Front Pads >?		0.5	
Remove & Replace	Brake Components > Brakes, R&R > Front Pads >?		0.6	
Remove & Replace	Brake Components > Brakes, R&R > Front Pads >?		0.4	
Remove & Replace	Brake Components > Brakes, R&R > Rear Pads/Sh?	B	0.9	0.0
Remove & Replace	Brake Components > Brakes, R&R > Rear Pads/Sh?		0.2	
Remove & Replace	Brake Components > Brakes, R&R > Rear Pads/Sh?		0.3	
Remove & Replace	Brake Components > Brakes, R&R > Rear Pads/Sh?		0.2	
Remove & Replace	Brake Components > Brakes, R&R > Rear Pads/Sh?		0.1	
Remove & Replace	Brake Components > Brakes, R&R > Rear Pads/Sh?		0.2	
Remove & Replace	Brake Components > Brakes, R&R > Rear Pads/Sh?		0.5	
Remove & Replace	Brake Components > Brakes, R&R > Rear Pads/Sh?		0.6	
Remove & Replace	Brake Components > Brakes, R&R > Rear Pads/Sh?		0.4	

Specifications Quick Reference (itype_439)

Quick Specifications

- item