

Component Procedures: Compressor Clutch

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Compressor Clutch

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Compressor > Clutch, R&R	B	1.8	0.0