

Component Procedures: Parking Brake System

Table of Contents

1. Parts and Labor (itype_189)
2. Parking Brake System - Components and Components Location (Article 45185)

Component Procedures: Parking Brake System

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Parking Brake	59750F2000	Front Cable	42.58	
Parking Brake	59710F2000TRY	Parking Brake Control	253.85	Order By Description.
Parking Brake > Rear Cable > ?	59760F2100	Disc Brakes	184.31	
Parking Brake > Rear Cable > ?	59760F2000	Drum Brakes	184.31	
Parking Brake > Rear Cable > ?	59770F2100	Disc Brakes	195.00	
Parking Brake > Rear Cable > ?	59770F2000	Drum Brakes	184.31	


Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Adjust	Parking Brake > Brakes, Adjust	B	0.4	0.0
Remove & Replace	Parking Brake > Parking Brake Control, R&R	B	0.4	0.0
Remove & Replace	Parking Brake > Rear Cable, R&R > One Side	B	1.3	0.0
Remove & Replace	Parking Brake > Rear Cable, R&R > Both Sides	B	1.6	0.0
Remove & Replace	Switches > Park Brake Warning Switch, R&R	B	0.5	0.0


Parking Brake System - Components and Components Location (Article 45185)

- Components

[Disc Type]



1. Parking brake lever 2. Equalizer assembly 3. Parking brake cable 4. Brake disc 5. Brake caliper
[Drum Type]



1. Parking brake lever 2. Equalizer assembly 3. Parking brake cable 4. Drum brake