

Component Procedures: Starter Solenoid

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Starter Solenoid

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Starter	361202E500	Solenoid	143.89	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Starter > Solenoid, R&R	B	1.1	0.0