

# Component Procedures: Expansion Valve

## Table of Contents

1. Parts and Labor (itype\_189)

# Component Procedures: Expansion Valve

## Parts and Labor (itype\_189)

### Parts

Qualifier	Part #	Name	Price	Note
Air Conditioner	97626A7000	Expansion Valve	163.77	

### Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Air Conditioner > Expansion Valve, R&R	B	0.5	0.0