

Component Procedures: Antenna, Navigation

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Antenna, Navigation

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Navigation System > Antenna, R&R	B	3.5	0.0