

Component Procedures: Marker Lamp

Table of Contents

1. Components (itype_389)
2. Procedures (itype_376)

Component Procedures: Marker Lamp

Components (itype_389)

CAUTION

: Do not use bulbs that have a higher candle power than the bulb listed. Damage to lamp can result. Do not touch halogen bulbs with fingers or other oily surfaces. Bulb life will be reduced.

Front

Side Marker

= 168 or W3W

Procedures (itype_376)

REMOVAL

1. From underside of the fender, remove nut attaching marker lamp to fender.
2. Separate lamp from fender.
3. Rotate bulb socket one-third turn counter-clockwise and separate socket from lamp housing.

INSTALLATION

1. Position bulb socket in lamp housing and rotate bulb socket one-third turn clockwise.
2. Position lamp in fender.
3. Install nut attaching marker lamp to fender.