

Component Procedures: Glove Compartment

Table of Contents

1. Parts and Labor (itype_189)
2. Instrument Panel Compartment Replacement (Article 10055)
3. Instrument Panel Compartment Door Latch Release Rod Replacement (Article 10053)
4. Instrument Panel Compartment Door Foundation Replacement (Article 10052)
5. Instrument Panel Compartment Door Assembly Replacement (Article 10050)
6. Instrument Panel Compartment Door Latch Replacement (Article 10054)
7. Instrument Panel Compartment Door Dampener Replacement (Article 10051)

Component Procedures: Glove Compartment

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Instrument Panel > Lock Cylinder, R&R	B	0.3	0.0
Remove & Replace	Instrument Panel > Lock Cylinder, R&R > NOTE ?		0.3	

Instrument Panel Compartment Replacement (Article 10055)

Callout Component Name

Preliminary Procedures Disconnect the instrument panel compartment door dampener from the compartment assembly. Squeeze the sides of the instrument panel compartment assembly allowing the compartment to open past the stops.

Preliminary Procedures

- Disconnect the instrument panel compartment door dampener from the compartment assembly.
- Squeeze the sides of the instrument panel compartment assembly allowing the compartment to open past the stops.

1 Instrument Panel Compartment Assembly Procedure Unsnap the instrument panel compartment assembly from the instrument panel.

Procedure

Unsnap the instrument panel compartment assembly from the instrument panel.

Instrument Panel Compartment Door Latch Release Rod Replacement (Article 10053)

Callout Component Name

1 Instrument Panel Compartment Door Refer to Instrument Panel Compartment Door Assembly Replacement .
2 Instrument Panel Compartment Door Latch Release Rod - Right Procedure Unsnap the release rod from the latch assembly and the guide.

Procedure

Unsnap the release rod from the latch assembly and the guide.

3 Instrument Panel Compartment Door Latch Release Rod - Left Procedure Unsnap the release rod from the latch assembly and the guide.

Instrument Panel Compartment Door Foundation Replacement (Article 10052)

Callout Component Name

Preliminary Procedure Remove the instrument panel compartment assembly. Refer to Instrument Panel Compartment Replacement .

Preliminary Procedure

Remove the instrument panel compartment assembly. Refer to Instrument Panel Compartment Replacement .

1 Instrument Panel Compartment Door Fasteners (Qty: 4) Caution: Refer to Fastener Caution . Tighten 2.5 Nm (22 lb in)

2.5 Nm (22 lb in)

2 Instrument Panel Compartment Door

3 Instrument Panel Compartment Door Foundation

Instrument Panel Compartment Door Assembly Replacement (Article 10050)

Callout Component Name

Preliminary Procedure Remove the instrument panel compartment assembly. Refer to Instrument Panel Compartment Replacement .

Preliminary Procedure

Remove the instrument panel compartment assembly. Refer to Instrument Panel Compartment Replacement .

1 Instrument Panel Compartment Door Fasteners (Qty: 4) Caution: Refer to Fastener Caution . Tighten 2.5 Nm (22 lb in)

2.5 Nm (22 lb in)

2 Instrument Panel Compartment Door Procedure When replacing the instrument panel compartment door assembly, transfer all necessary components.

Procedure

When replacing the instrument panel compartment door assembly, transfer all necessary components.

Instrument Panel Compartment Door Latch Replacement (Article 10054)

Callout Component Name

1 Instrument Panel Compartment Door Refer to Instrument Panel Compartment Door Assembly Replacement .

2 Instrument Panel Compartment Door Latch Fasteners (Qty: 2) Caution: Refer to Fastener Caution . Tighten 2.5 Nm (22 lb in)

2.5 Nm (22 lb in)

3 Instrument Panel Compartment Door Latch Assembly Procedure Unsnap the instrument panel compartment door latch release rods from the latch assembly.

Procedure

Unsnap the instrument panel compartment door latch release rods from the latch assembly.

Instrument Panel Compartment Door Dampener Replacement (Article 10051)

Callout Component Name

Preliminary Procedures Remove the right instrument panel outer trim cover. Refer to Instrument Panel Outer Trim Cover Replacement . Remove the right instrument panel outer air outlet duct. Refer to Instrument Panel Outer Air Outlet Duct Replacement - Right Side . Remove the instrument panel assembly. Refer to Instrument Panel Assembly Replacement .

Preliminary Procedures

- Remove the right instrument panel outer trim cover. Refer to Instrument Panel Outer Trim Cover Replacement .

- Remove the right instrument panel outer air outlet duct. Refer to Instrument Panel Outer Air Outlet Duct Replacement - Right Side .

- Remove the instrument panel assembly. Refer to Instrument Panel Assembly Replacement .

1 Instrument Panel Carrier Support Bracket Fasteners (Qty: 3) Caution: Refer to Fastener Caution . Tighten 2.5 Nm (22 lb in)

2.5 Nm (22 lb in)

2 Instrument Panel Carrier Support Bracket

3 Instrument Panel Compartment Door Dampener Fasteners (Qty: 2) Tighten 2.5 Nm (22 lb in)

4 Instrument Panel Compartment Door Dampener Assembly